



THE BEST TARP REPAIR KIT FROM T.R.S. INDUSTRIES AND HH-66

- 1. Repair must be made where the temperature is above 60 degrees.**
- 2. Clean tarp with the thinner supplied.**
- 3. Cut patch to size required (patch should be at least 2" larger than the hole on all sides).**
- 4. Draw around patch to mark the area for gluing.**
- 5. Apply glue to the tarp and patch, let it dry until tacky (30 to 60 seconds).**
- 6. Press patch on tarp and let it set up for 1 to 12 hours.**
- 7. This glue strengthens with age; however,**
- 8. THIS IS ONLY A TEMPORARY PATCH! Call us at 800-246-1749 for more information.**